

- de** Montageanleitung
- en** Mounting instructions
- fr** Instructions de montage
- sv** Monteringsinstruktion
- nl** Montage-aanwijzing
- it** Istruzioni di montaggio
- fi** Asennusohje
- es** Instrucciones de montaje
- da** Monteringsvejledning
- tr** Montaj talimatları

**QFM...**

**A**

1864ZD3

**B**

1864M03

**C**

1864ZD1

**For US and Asia Pacific only:**

1761ZD0M

<p><b>G</b> AC 24 V ±20 % / DC 13,5...35 V</p> <p><b>G0</b> GND</p> <p><b>X...</b> 4...20 mA / DC 0...10 V / 0...5 V</p>	<p><b>B</b> </p> <p><b>M</b> </p>
<p><b>I...</b> 4...20 mA</p> <p><b>G...</b> DC 13,5...35 V</p>	<p><b>BS</b> </p> <p><b>MS</b> </p> <p style="text-align: right; font-size: x-small;">1761ZD06</p>

**Open Source Software (OSS)**

All open source software components used within the product (including their copyright holders and the license conditions) can be found from the website <https://www.siemens.com/download?A6V12393975>.

Issued by  
Siemens Switzerland Ltd  
Smart Infrastructure  
Global Headquarters  
Theilerstrasse 1a  
CH-6300 Zug  
Tel. +41 58 724 2424  
[www.siemens.com/buildingtechnologies](http://www.siemens.com/buildingtechnologies)

© Siemens Switzerland Ltd, 2004  
Technical specifications and availability subject to change without notice.